

// INSTALLATION GUIDELINES

Recommended ALDILA® installation instructions. Legacy Installation Guidelines apply to most pre-2018 ALDILA golf shafts.

Please consult the ALDILA® website (www.aldila.com) or your ALDILA Sales Representative for more information (858) 513-1801

LEGACY

Trim Code	Procedure
A	Trim to length from butt end.
B	Tip Trim in 1/2" increments (3-PW).
C	Tip Trim in 1/2" increments (3W-7W).
D	Tip Trim Driver 2", 3W 2-1/2", 4W 3", 5W-7W 3-1/2".
E	Tip Trim 2", then 1/2" increments (3-PW).
F	No Tip Trim for Driver. Trim to length from butt end. Tip Trim Fairway Woods 1", then to length from butt end. For hosel designs with bore thru depths greater than 2", we recommend blind boring the shaft in the hosel 1-3/4".

WOODS

Driver	3 Wood	5 Wood	7 Wood	9 Wood
0"	0.5"	0.75"	1.0"	1.0"

HYBRIDS

1i/4w	2i/5w	3i/7w	4i/9w	5i/11w
0"	0.5"	1.0"	1.5"	2.0"

IRONS (UNITIZED)

2h/i	3h/i	4h/i	5h/i	6h/i	7h/i	8h/i	9h/i	PW
0"	0"	0.5"	1.0"	1.5"	2.0"	2.5"	3.0"	3.5"

¹ All golf shafts are design to be butt trimmed to length.

² Golf shaft installation should only be completed by a qualified, trained golf club builder. To find an authorized ALDILA® account in your area, please visit our website.